

Mounting instruction

Ecoflex 10[®] / Aircom Premium[®] N-Angle-Connector / Art. No.: 7360



Required tools :

- 1 x open-ended spanner 17 mm
- 1 x open-ended spanner 18 mm
- 1 x Cutter knife
- 1 x scissors
- 1 x soldering station



Cut off cable tail right-angled.



Move the nut, clamping ring and rubber washer over the cable tail.



Remove 16 mm of the outer sheath with the knife.



Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.



Mark out and remove the copper foil with a knife. Short the dielectric to a length of 10 mm.



The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 17/18 mm. A small split should remain visible between clamping nut and connector housing.



Then the inner conductor has to be soldered to the center contact. Screw down closure cap firmly.