

# Mounting instruction

## Ecoflex<sup>®</sup> 10 / Aircom<sup>®</sup> Premium SMA-RP-Connector / Art. No.: 7365



### Required tools :

- 2 x open-ended spanner 17 mm
- 1 x Cutter knife
- 1 x scissors




1 Cut off cable tail right-angled.



2 Move the nut, clamping ring and rubber washer over the cable tail.



3 Remove 4,5 mm of the outer sheath with a knife.



4 Bend copper braid upwards right-angled. Insert contact sleeve between copper foil and braid until stop. Cut off protruding braid. Move the rubber seal to the front, up to the contact sleeve.



5 Remove the copper foil and the dielectric with a knife.



6 Attach inner pin to the inner conductor and solder carefully.

Hint:

Pin 1: 2,8mm Ø Aircom Premium

Pin 2: 3,0mm Ø Ecoflex 10.



7 The prepared cable tail has to be inserted into the housing until stop. Tighten the clamping nut finger tight with two open-ended spanners 16 mm. A small split should remain visible between clamping nut and connector housing.