

Montageanleitung



AIRCELL®7

UHF-Connector, full crimp / item No.:7400



Cut the cable end at right angles.
Push the sleeve and hose over the cable end.



Remove the outer mantle with a knife or stripper 28-29mm.
(To simplify removal, we recommend slitting the piece to be removed with a knife)



Bend up the copper braid at a right angle. Remove 16mm from the copper foil and the dielectric in order to uncover the inner conductor. (Caution: inner conductor wires must remain together)



Insert inner conductor into sleeve and center contact. Mount the housing until it reaches the cable end.



Bend the braid back and push over the Crimpule. After that, cut off the overlapping braid and crimp. (8.2mm crimp tool)



Crimp the central contact.
(2.4mm crimp tool)



Push heat shrink tube forward until it reaches the housing and heat it evenly with a hot air fan.

This completes the assembly.