

# Mounting instruction

## AIRCELL®5

N-Cocket, crimp / item. No.: 7703



1  
Cut off cable tail right-angled. Move the crimp-cover over the cable head. Cut off 14 mm of the outer sheathing with a knife.



2  
Bend copper braid upwards right-angled.



3  
Slit slightly a length of 6 mm of the copper foil and remove it.



4  
Remove 4 mm of the dielectric.



5  
Put the head pin onto the inner conductor and crimp it (0,213 Inch).



6  
Insert the prepared cable end into the connctor housing as far as it will go (Click).



7  
Cut off the copper raid with a side cutter and move the crimp jacket to the front.



8  
Crimp the crimp jacket with a crimp tool; herewith the copper braid will be trapped between the crimp jacket and the connector housing.