

Mounting instructions



AIRCELL®5

BNC-Male, crimp / item. no.: 7721



Cut off the cable end at right angles. Push the crimp sleeve over the cable end. Remove 16mm of the outer jacket.



Twist the copper braid at right angles.



Remove 4mm of the copper foil with a knife.



Remove 4mm of the foamed dielectric.



Place the inner pin on the conductor and solder / crimp.



Push the end of the cable thus prepared up to the Stop (click) in the connector housing.



Cut the copper braid with the side cutter. And move the crimp sleeve forward.



Crimp the crimp sleeve with the crimping plier, so that the copper braid is clamped between the plug housing and the crimping sleeve.