

Mounting instruction

ECOFLEX® 5

UHF-Stecker, crimp / Item. No.: 7762-E



Required tools:

- 1 x Cutter knife
- 1 x Wire cutter
- 1 x Crimp insert 0.255" (6,47 mm)



1 Cut off cable tail right-angled. Slide the crimp sleeve over the cable end. Remove 28 mm of the outer jacket with the knife.



2 Bend the copper braid backwards. Slit slightly 22 mm of the copper foil and remove it. Then remove 15 mm of the dielectric.



3 Insert the prepared cable head into the connector housing as far as it will go.



4 Solder the inner conductor and the inner pin at the tip.



5 Cut off the copper braid with a wire cutter and move the crimp jacket to the front.



6 Crimp the crimp jacket with a crimp tool; herewith the copper braid will be trapped between the crimp jacket and the connector housing.