

# Data sheet / instructions for use



## LNA 200 Art.No.:1011-NF



### Product description

The LNA 200 is a robust, selective and low-noise reception preamplifier for the 2 m amateur radio band. This amplifier is characterized by a high gain and very good large-signal behavior. The input and output networks of the amplifier are dimensioned so that both connections have an exact 50 ohm impedance with very low imaginary components. This ensures that the antenna system is loaded with real 50 ohms. With the highly optimized narrowband antennas that are often used at the moment, it is very important that they are terminated with real 50 ohms. Mismatch at the input of the preamplifier used can lead to a change in the parameters of such antennas, which reduce the antenna gain and influence the directional characteristic. This amplifier is built with a GaAs MMIC of the latest technology on a high quality microwave substrate in SMD technology. The input circuit of the amplifier is built with HQ components in a cell design and optimized for the best noise properties. The band pass with HQ elements at the output of the amplifier ensures good band selection. This effectively suppresses signals that lie outside the useful band and relieves the downstream receiver. The LNA 200 preamplifier is ideal for EME, Meteorscatter, Aurora, Troposcatter and contest operations.

### Technical specifications

Frequency range:	144....146 MHz
Noise figure @ 20°C NF:	0,5 dB
Gain S21, typ.:	21 dB
Return loss:	
Input S11:	22 dB
Output S22:	21 dB
OIP3:	31 dBm
IIP3:	10 dBm
Max. Input level:	20 dBm
Operating voltage:	8 ....14 V
Power consumption:	110 mA
Housing dimensions:	74 x 51 x 30 mm
Weight:	140 g
Connection standard:	N-Connector female

### Connection instructions

The voltage supply of the preamplifier can be fed via the coaxial output line with the help of a remote feeder (e.g. DCC 5000pro), which is connected upstream of the receiver input. For receivers that send the LNA power supply to the antenna input, the coaxial

output line of the preamplifier is connected directly to the antenna input of the receiver. This preamplifier can also be locally supplied with voltage from a power supply unit via the +12 V DC connection. The shortest possible low-loss coaxial cable, e.g. Ecoflex 15 or Ecoflex 10, should be used for the antenna connection. The output line can be implemented with a thinner coaxial cable, e.g. Aircell 7. The coaxial cables used should not have transforming lengths. The lengths are calculated using the following formula:

$$\text{Lambda} / 2 \times N \times V.$$

Lambda - wavelength

N - natural number 1 2 3 4 5 .....

V - Velocity factor of the coaxial cable used.

### Attention!

The LNA 200 has no transmitter/receiver switching. Too high signal levels at the input or output of the amplifier can damage the device.

### Notes on environmental protection



Electrical and electronic devices may not be disposed of with household waste. This must be handed in separately at collecting points, or returned to the point of sale. Packaging materials must be separated and disposed of through the municipal waste by material type.

### Maintenance

Do not open the unit. It does not contain any parts needing maintenance. If you need help regarding technical matters, please contact [support@ssb-electronic.com](mailto:support@ssb-electronic.com). For a lowest possible noise figure of the complete system, set preamp to maximum gain.

### Safety, Warranty

Not suitable for children! The packaging material and the device may contain small parts which may be swallowed. Repairs may only be performed by qualified personnel., Opening the device, or improper use will void any warranty claims. No guarantee will be given. The device applies to the Low Voltage Directive 2006/95/EG, as well as to 2004/108/EG, 2002/96/EG, 1999/44/ EG.

### Declaration of Conformity



The CE mark is a free trade mark. It does not guarantee any product features. The product does apply all relevant regulations within the scope of 94/62/EG.

Manufacturer is: SSB-Electronic GmbH,  
Am Pulverhäuschen 4, 59557 Lippstadt/Germany

Technical changes are reserved. Contents of this document are the intellectual property of SSB-Electronic GmbH. Reproduction is only permitted with the express written approval.

### How to contact:

E-Mail: [support@ssb-electronic.com](mailto:support@ssb-electronic.com)  
Phone: +49 (0) 2941-93385-0  
Internet: [www.ssb.com](http://www.ssb.com)