

# Mounting instructions

EcOFLEX@10,  
ECOFLEX@10 Plus,  
AIRCOM Plus

N-Connector male crimp/solder item. no.  
7366



**1.** Cut the cable end at right angles. Push the crimp sleeve and the anti-kink hose over the cable end. Remove with a 17 mm blade of the outer mantle.



**5.** Cut the copper braid with the side cutter. Push the sleeve as far as it will go



**2.** Twist the copper braid at right angles. Using a 5 mm knife, etch and remove the copper foil and the foamed dielectric



**6.** Crimp the crimping sleeve with the crimping tool, so that the copper braid is clamped between the connector housing and the crimping sleeve.



**3.** Place the inner pin on the conductor and solder it through the hole.



**7.** Move the anti-kink hose to the front until it hits the trigger and warm it with the hot hair dryer.



**4.** Insert the end of the cable thus prepared as far as the stop (click) into the plug housing. Twist the copper braid at right angles.

SSB- Electronic GmbH · Am Pulverhäuschen 4 · 59557 Lippstadt · Germany

[www.ssb.de](http://www.ssb.de)

19/11/2016