









Mounting instruction

AIRCELL®5

TNC-Socket, screw/solder / Art. No. 7742



 <p>1. Cut off cable tail right-angled.</p>	 <p>5. Move the contact sleeve as far it goes between the copper braid and the foil. Slice 5mm of the copper foil and 4mm of the foamed dielectric with a sharp knife and remove it.</p>
 <p>2. Move the nut, clamping ring and rubber washer over the cable head.</p>	 <p>6. Cut off the copper braid with a side cutter and move the rubber washer forward to the contact sleeve, so that the remaining braid is clamped between the rubber washer and the contact sleeve.</p>
 <p>3. Remove 7 mm of the outer sheathing with a knife.</p>	 <p>7. Put the inner pint onto the inner conductor and solder it. There should be left a distance of 1mm between the inner pin and the copper foil.</p>
 <p>4. Bend copper braid upwards right-angled.</p>	 <p>8. Insert the prepared cable end into the connector housing as far as it will go. Take two open-end wrenches 11mm to tighten the clamping nut hand-tight.</p>