








Mounting instruction



AIRCELL®5

SMA-Angle Connector, crimp/solder / Art. No. 7752

 <p>1. Cut off cable tail right-angled. Move the crimp sleeve over the cable tail.</p>	 <p>5. Insert the so prepared cable end into the connector housing as far it goes (click).</p>
 <p>2. Remove 13mm of the outer sheathing with a knife. Bend copper braid upwards right-angled.</p>	 <p>6. Cut off the copper braid and move the crimp sleeve forward. Put the inner pin onto the inner conductor and solder it.</p>
 <p>3. Remove 5mm of the copper foil with a knife.</p>	 <p>7. Crimp the crimp sleeve with a crimp tool; herewith the copper braid will be clamped between the socket housing and the crimp sleeve. Screw cap firmly.</p>
 <p>4. Remove 3mm of the foamed dielectric.</p>	