









# Mounting instruction



## AIRCELL®5

BNC-Socket, screw/solder / Art. Nr. 7722

 <p><b>1.</b> Cut off cable tail right-angled.</p>	 <p><b>5.</b> Move the contact sleeve as far it goes between the copper braid and the foil. Slit 6 mm of the copper foil with a sharp knife and remove it, then remove 5mm of the foamed dielectric.</p>
 <p><b>2.</b> Move the nut, clamping ring and rubber washer over the cable head.</p>	 <p><b>6.</b> Cut off the copper braid with a side cutter and move the rubber washer forward to the contact sleeve, so that the remaining braid is clamped between the rubber washer and the contact sleeve.</p>
 <p><b>3.</b> Remove 7mm of the outer sheathing with a knife.</p>	 <p><b>7.</b> Attach the inner pin to the tip and solder through the hole. There should be a space of 1 mm between the inner pin and the copper foil.</p>
 <p><b>4.</b> Bend copper braid upwards right-angled.</p>	 <p><b>8.</b> Insert the prepared cable end into the connector housing as far as it will go (Click). Take two open-end wrenches 11/13 mm to tighten the clamping nut hand-tight.</p>